# Original Operating Instructions C-VLR 60 | 100 | 150 | 251

Vacuum pump





# Contents

# **Contents**

1	Foreword	4
1.1	Principles	4
1.2	Target group	4
1.3	Supplier documentation and accompanying documents	4
1.4	Abbreviations	4
1.5	Directives, standards, laws	4
1.6	Symbols and meaning	5
1.7	Technical terms and meaning	5
1.8	Copyright	5
2	Safety	6
2.1	Warning instruction markings	6
2.2	General	6
2.3	Designated use	7
2.4	Unacceptable operating modes	7
2.5	Personal qualifications and training	8
2.6	Safety-conscious work	8
2.7	Safety notes for the operator	8
2.8	Safety instructions for installing, commissioning and maintenance	9
2.9	Guarantee conditions	9
3	Transport, storage and disposal	10
3.1	Transportation	10
	3.1.1 Unpack and check the delivery condition	10
	3.1.2 Lifting and transporting	10
3.2	Storage	11
0	3.2.1 Ambient conditions for storage	11
3.3	Disposal	11
4	Set up and operation	12
4.1	Setup	12
	4.1.1 Data plate	15
4.2	Description	15
4.3	Areas of application	16
5	Installation	17
5.1	Preparing for installation	17
5.2	Installation	17
5.3	Connecting pipes	18
5.4	Control and relief valve	18
5.5	Filling with lubricating oil	19
5.6	Connecting the motor	19
6	Commissioning and decommissioning	20
6.1	Commissioning	20
	6.1.1 Checking the rotation direction	21
6.2	Decommissioning/ storing	21
6.3	Re-commissioning	21



# Contents

7	Maintenance and repair	. 22
7.1	Ensuring operational safety	. 22
7.2	Maintenance work	. 22
	7.2.1 Changing the oil	. 23
	7.2.2 Air filtering	. 24
	7.2.3 Clutch	
7.3	Repair/ Service	. 26
7.4	Spare parts	. 27
8	Malfunctions: Causes and elimination	. 28
9	Technical Data	29



## 1 Foreword

# 1.1 Principles

These operating instructions:

- Are part of the following contact free running claw vacuum pumps of type C-VLR60, C-VLR100, C-VLR150, and C-VLR251.
- describe how to use them safely and properly in all life phases.
- must be available where the equipment is used.

# 1.2 Target group

The target group for these instructions is technically trained specialists.

# 1.3 Supplier documentation and accompanying documents

Document	Contents	No.
	Operating Instructions	BA 880-EN
Supplier documentation	Declaration of Conformity	C 0080-EN
	Declaration of harmlessness	7.7025.003.17
Spare parts' list	Spare parts document	E 880
Data sheet	Technical data and characteristics	D 880 / D 880-31
Info sheet	Storage guidelines for machines	I 150
Manufacturer's declaration	EU Directive 2011/65/EU (RoHS II)	_

# 1.4 Abbreviations

Fig. Figure

C-VLR Vacuum pump

m³/h Suction capacity

mbar (abs.) Final vacuum, operating vacuum

\* Picture shows possibly optional asseccories

## 1.5 Directives, standards, laws

See Conformity Declaration



# 1.6 Symbols and meaning

Symbol	Explanation
$\triangleright$	Condition, pre-requisite
####	Instructions, action
a), b),	Instructions in several steps
⇒	Results
□ [-> 14]	Cross reference with page number
i	Information, note
$\triangle$	Safety symbol Warns of potential risk of injury Obey all the safety instructions with this symbol in order to avoid injury and death.

# 1.7 Technical terms and meaning

Term	Explanation	
Machines	Pump and motor combination ready to be connected	
Motor	Pump drive motor	
Vacuum pump	Machine to create a vacuum	
Claw	Machine's design or active principle	
Suction capacity	Vacuum pump volume flow related to the condition in the suction connection	
Final pressure (abs.)	The maximum vacuum that a pump reaches when the suction opening is closed. Given as absolute pressure	
Permanent vacuum	The vacuum or the suction range at which the pump operates permanently.  The permanent vacuum or intake pressure is ≥ than the final vacuum and < than the atmospheric pressure.	
Noise emission	The noise emitted at a specific loading given as a figure, sound pressure level dB(A) as per EN ISO 3744.	

# 1.8 Copyright

Passing on or copying this document, using and providing information on its contents are prohibited unless expressly permitted. Contraventions will lead to claims for damages.



# 2 Safety

The manufacturer is not responsible for damage due to nonobservance of the whole documentation.

#### 2.1 Warning instruction markings

Warning	Danger level	Consequences if not obeyed
<b>A</b> DANGER	Immediately imminent danger	Death, severe bodily injury
WARNING	Possible imminent danger	Death, severe bodily injury
<b>CAUTION</b>	Possible hazardous situation	Slight bodily injury
NOTICE	Possible hazardous situation	Material damage

#### 2.2 General

These operating instructions contain basic instructions for installation, commissioning, maintenance and inspection work which must be obeyed to ensure the safe operation of the machine and prevent physical and material damage.

Observe the safety instructions in all chapters. The operating instructions must be read by the responsible technical personnel/ operator before installing and commissioning/and must be fully understood. The contents of the operating instructions must always be available on site for the technical personnel/operator. Instructions fixed directly onto the machine must be obeyed and must always remain legible. This applies for example to:

- Symbols for connections
- Data and motor data plate
- Instruction and warning plates

The operator is responsible for observing local regulations.



# 2.3 Designated use

The machine must only be operated in such areas as are described in the operating instructions:

- only operate the machine in a technically perfect condition
- do not operate the machine when it is only partially assembled
- the machine must only be operated at an ambient temperature and suction temperature of between 5 and 40°C.
  - Please contact us for temperatures outside this range.
- the machine may convey, compress or extract the following media:
  - All non-explosive, non-inflammable, non-aggressive and non-poisonous dry gases and gas air mixtures

## 2.4 Unacceptable operating modes

- extracting, conveying and compressing of explosive, inflammable, aggressive or poisonous media, e.g. dust as per ATEX zone 20-22, solvents as well as gaseous oxygen and other oxidation agents, water vapour, liquids or solids
- Using the machine in non-commercial plants if the necessary precautions and protective measures have not been taken in the plant
- installing in environments that are at risk of explosions
- Using the machine in areas with ionising radiation
- Modifications to the machine and accessories



# 2.5 Personal qualifications and training

- Ensure that people entrusted with working on the machine have read and understood these operating instructions before starting work, particularly the safety instructions for installation, commissioning, maintenance and inspection work
- Manage the responsibilities, competence and monitoring of staff
- All work must only be carried out by technical specialists:
  - Installation, commissioning, maintenance and inspection work
  - Working with electricity
- Personnel being trained to work on the machine must be supervised by technical specialists only

# 2.6 Safety-conscious work

The following safety regulations apply in addition to the safety instructions and intended use listed in these instructions:

- Accident prevention regulations, safety and operating regulations
- Standards and laws in force

# 2.7 Safety notes for the operator

- Hot parts of the machine must not be accessible during operation or must be fitted with a guard
- People must not be endangered by the free extraction or discharge of pumped media
- Risks arising from electrical energy must be eliminated
- The machine may not get in contact with flammable materials.
   Risk of fire due to hot surfaces, output of hot pumped media or cooling air



# 2.8 Safety instructions for installing, commissioning and maintenance

- The operator will ensure that any installation, commissioning and maintenance work is carried out by authorised, qualified specialists who have gained sufficient information by an in-depth study of the operating instructions.
- Only work on the machine when it stands still and is secured against accidental switching on
- Strictly observe the procedure for decommissioning of the machine described in the operating instructions
- Fit or start up safety and protective devices again immediately after finishing work. Before recommissioning, follow the instructions listed for commissioning
- Alteration works or modifications to the machine are only permissible with the manufacturer's consent
- Only use original parts or parts approved by the manufacturer. The use of other parts can void liability for any consequences arising
- Keep unauthorised people away from the machine

## 2.9 Guarantee conditions

The manufacturer's guarantee or warranty will no longer apply in the following cases:

- Improper use
- Not complying with these instructions
- Operation by insufficiently qualified staff
- using spare parts that have not been approved by Gardner Denver Schopfheim GmbH
- Unauthorised modifications to the machine or the accessories supplied by Gardner Denver Schopfheim GmbH



# 3 Transport, storage and disposal

## 3.1 Transportation

# 3.1.1 Unpack and check the delivery condition

#### 3.1.2 Lifting and transporting



Fig. 1 Lift and transport

## 1 Eyebolt

- a) Unpack the machine on receipt and check for transport damage.
- Notify the manufacturer of transport damage immediately.
- c) Dispose of the packaging in accordance with the local regulations in force.

# A

#### WARNING

Death or limbs crushed as a result of the items being transported falling or tipping over!

- When transporting with the lifting device remember:
- a) Select the lifting device suitable for the total weight to be transported.
- b) That the machine is secured against tipping and falling.
- c) Do not stop under a suspended load.
- d) Put the goods to be conveyed on a horizontal base.

## Lifting device/ Transporting with a crane



#### WARNING

#### Bodily injury resulting from improper operation

- a) Loads crosswise to the ring level are not permitted.
- b) Avoid impact stress.
- a) Tighten the eyebolt (Fig. 1/1) firmly.
- b) The machine must be suspended on the eyebolt using the lifting device for lifting and transporting.



# 3.2 Storage

## **NOTICE**

# Material damage caused by improper storage

- Ensure that the storage area meets the following conditions:
- a) Dust-free
- b) Vibration-free

# 3.2.1 Ambient conditions for storage

Ambient conditions	Value
Relative humidity	0 % to 80 %
Storage temperature	-10°C to +60°C



The machine must be stored in a dry environment with normal air humidity. It should not be stored for more than 6 months.

See Info "Machine storage guidelines", Page 4

# 3.3 Disposal



## **WARNING**

# Danger due to flammable, corrosive or poisonous substances!

Machines that come into contact with hazardous substances must be decontaminated before disposal!

- When disposing of ensure the following:
- a) Collect oils and grease separately and dispose of in accordance with the local regulations in force.
- b) Do not mix solvents, lime-scale removers and paint residues.
- c) Remove components and dispose of them in accordance with the local regulations in force.
- d) Dispose of the machine in accordance with the national and local regulations in force.
- e) Parts subject to wear and tear (marked as such in the spare parts list) are special waste and must be disposed of in accordance with the national and local waste laws.



# 4 Set up and operation

# 4.1 Setup




Fig. 2 Vacuum pump C-VLR 60

Α	Vacuum connection
В	Exhaust air-outlet
С	Vacuum regulating valve / limitation valve*

Е	Cooling air-inlet
F	Cooling air outlet
Н	Oil filling point

I Oil sight glass

K Oil discharge point

M	l Oi	recommend	lation	plate
---	------	-----------	--------	-------

N Data plate

O Rotation direction plate


P Drive motor

**P**<sub>1</sub> Motor data plate

Q Hot surfaces > 70 °C

**S** Intake filter

**Z** Exhaust silencer






Fig. 3 Vacuum pump C-VLR 150

- A Vacuum connection
- B Exhaust air-outlet
- C Vacuum regulating valve / limitation valve\*
- E Cooling air-inlet
- F Cooling air outlet
- **H** Oil filling point
- I Oil sight glass
- **K** Oil discharge point

- M Oil recommendation plate
- N Data plate
- O Rotation direction plate
- P Drive motor
- **P**<sub>1</sub> Motor data plate
- Q Hot surfaces > 70 °C
- **S**<sub>1</sub> Terminal box
- **Z** Exhaust silencer






Fig. 4 Vacuum pump C-VLR 251

- A Vacuum connection
- **B** Exhaust air-outlet
- C Vacuum regulating valve
- E Cooling air-inlet
- F Cooling air outlet
- **H** Oil filling point
- I Oil sight glass
- K Oil discharge point

- M Oil recommendation plate
- N Data plate
- O Rotation direction plate
- P Drive motor
- Q Hot surfaces > 70 °C
- S₁ Terminal box
- **Z** Exhaust silencer



Κ

# 4.1.1 Data plate




Fig. 5 Data plate (example)

- 1 Type / Size (mechanical version)
- 2 Year of construction
- 3 Motor design
- 4 Serial number
- 5 Item-No.
- **6** Final pressure (abs.)
- 7 Suction capacity 50 Hz/60 Hz
- 8 Speed 50 Hz/60 Hz
- 9 Motor output 50 Hz/60 Hz
- 10 Operating mode

## 4.2 Description

The C-VTR model range has a connecting thread on the suction side and an exhaust silencer on the pressure side. With the C-VLR 60 the incoming air is cleaned by a filter cartridge. C-VLR 100-251 have a micro filter on the suction side.

The ZEPHYR C-VLR is a double shaft rotary piston vacuum pump in which the claws roll off against each other contact free and dry. The counter-rotating claw rotors are synchronised by a gear pair in the gearbox. The synchronous gearbox gear wheels and the bearing on the motor side are lubricated with oil. These components are in a gearbox that also contains the oil supply. Oil conveying devices always ensure that the bearings and the gear wheels are sufficiently supplied with oil at all permissible speeds. The feed chamber has no sealants or lubricants.

The gearbox and the compression chamber are separated from each other by special seals. The gearbox is sealed from the outside with piston sealing rings and O rings, the compressor chamber with piston rings. Between the two there is also another atmospherically ventilated area that can be loaded with sealing gas (special version).

The C-VLR 100-251 is enclosed in an insulation hood.

In order to dissipate compression heat, the cooling air is sucked through between the machine and the hood using drum fan that sucks in the fresh cooling air (Fig. 3/E) and discharges the heated air out of the cooling air outlet (Fig. 3/F).

The C-VLR is driven by standard flanged three phase motors via a clutch (with an elastomer component). A vacuum control valve (Fig. 3/C) allows setting of the desired vacuum.



# 4.3 Areas of application

These contact-free running claw vacuum pumps, the C-VLR, can be operated constantly at any pressure between atmosphere and an inlet pressure of

60 mbar (abs.)  $\rightarrow$  C-VLR 60 (31+32)/100 (31)/150 (31)

100 mbar (abs.) → C-VLR 60/150

150 mbar (abs.) → C-VLR 100

200 mbar (abs.) → C-VLR 251

The suction capacity with unrestricted suction is 60, 100, 150 and 215 m<sup>3</sup>/h at 50 Hz. Data sheet D-880 or D 880-31 shows the dependency of the suction capacity on the intake pressure.



If the unit is switched on more frequently (at regular intervals of about 12 times an hour (C-VLR 60 – 150) or 10 times an hour (C-VLR 251)) at higher ambient temperatures and intake temperatures, the excess temperature limit of the motor winding and the bearings may be exceeded.

For such operating conditions contact the manufacturer.



If it is installed in the open air the unit must be protected from environmental influences, (e.g. by a protective roof).



#### 5 Installation

## 5.1 Preparing for installation

Check the following points:

- Machine freely accessible from all sides
- Do not close ventilation grids and holes
- Sufficient room for installing and removing pipes and for maintenance work, particularly for installing and dismantling the machine
- No external vibration effects
- Do not suck any hot exhaust air from other machines into the cooling system



Oil filling point (Fig. 2/H... Fig. 4/H), oil inspection glasses (Fig. 2/I... Fig. 4/I) and oil outlets (Fig. 2/K... Fig. 4/K) must be readily accessible.

The cooling air inlets (Fig. 2/E... Fig. 4/E) and the cooling air outlets (Fig. 2/F... Fig. 4/F) must be placed in distance of at least 30 cm to the adjacent walls. Cooling air coming out must not be sucked in again.

For maintenance work, before the intake filter (Fig. 2/S) and the intake silencer (Fig.  $3/S_1$ , Fig.  $4/S_1$ ) a minimum distance of 40 cm must be ensured.

#### 5.2 Installation

## **NOTICE**

The machine may only be operated when it is set up horizontally.

Material damage resulting from the machine tipping over and falling.

When installed at more than 1000 m above sea level a reduction in power is noticeable. In this case, please contact us.

#### Polluted intake air

To protect the machine, the user shall install the appropriate filters on the intake side.

Ensure that the foundation complies with the following conditions:

- Even and level
- The bearing surface must be designed to be able to carry the weight of the machine



It is possible to install the machine on a firm base without anchoring. When installing on a substructure we recommend fixing with flexible buffers.



# 5.3 Connecting pipes

a) Vacuum connection at (Fig. 2/A... 4/A).

## **NOTICE**

Material damage resulting from the forces and torques of the pipes acting on the unit being too high

Only screw pipes in by hand.

The suction capacity of the vacuum pump is reduced if the suction pipe is too narrow and/ or too long.

b) The extracted air can be blown off through the exhaust silencer (ZSZ) at (Fig. 2/Z... 4/Z) or can led out through a hose or tube line.

## NOTICE

## Length of the connection pipes

With connection pipes that have the same pipe cross section as the machine connection and are more than 3 m long, a non-return valve especially for the purpose must be installed in order to avoid reverse operation when the machine has stopped.

## Exhaust air may not be reduced

It is not allowed to install shut-off components in the exhaust lines (max. pressure difference 30 mbar). With the exhaust line connected, it must be checked regularly for pollution.

# 5.4 Control and relief valve

The vacuum can be set by turning the control knob (Fig.. 2/C... 4/C) as shown on the symbol fitted to the button.

#### NOTICE

# Do not operate without the standard control and relief valve

If the permissible vacuum is exceeded (see data plate) the machine may be damaged.



# 5.5 Filling with lubricating oil

- a) Fill the lubricating oil (for suitable types see "Maintenance") for the gear wheels and oil filling point (Fig. 3/H) up to the middle of the sight glasses (Fig. 3/I).
- b) Close the oil filling point.

# 5.6 Connecting the motor



# A

# **DANGER**

# Danger of to life if the electrical installation has not been done professionally!

The electrical installation must only be done by a qualified electrician observing EN 60204. The operating company has to provide the main switch.

- a) The electrical motor data is given on the data plate (Fig. 3/N, Fig. 5) or on the motor data plate (Fig. 3/P<sub>1</sub>). The motors comply with DIN EN 60034 and are in protection class IP 55 and insulation class F. The appropriate connection diagram is located in the motor's terminal box (not for the plug connection version). Compare the motor data with the data of the existing mains network (current type, voltage, network frequency, permitted current value).
- b) Connect the motor via the plug connection or the motor protection circuit breaker (for safety reasons, a motor protection circuit breaker is required and the connecting cable must be installed via a cable fitting to provide strain relief).
   We recommend using motor protection circuit breakers with delayed switch off, depending on a possible excess current. Temporary excess current can occur when the machine is started under cold conditions.

# **NOTICE**

#### **Power supply**

The conditions at the place of installation must meet the technical details on the motor type plate. Without derating the following conditions are permissible:

- ± 5 % voltage deviation
- ± 2 % frequency deviation



# 6 Commissioning and decommissioning

# 6.1 Commissioning



## **WARNING**

# Improper use

May lead to severe or fatal injuries. Therefore strictly observe the safety instructions!





# **CAUTION**

## Hot surfaces

When the machine is at operating temperature the surface temperatures on the components (Fig. 2/Q ...Fig. 4/Q) may go above 70 °C. Do not touch hot surfaces (marked with warning signs)!



# A

# **CAUTION**

# Noise emission

The highest noise pressure levels measured as per EN ISO 3744 are given in Section 9. When spending a long time in the vicinity of the running machine use ear protectors to avoid permanent damage to your hearing!



# Wait until the machine stops

The machine must only be switched on again after it stops.



# 6.1.1 Checking the rotation direction

- The intended direction of rotation of the drive shaft is shown by the rotary direction arrow (Fig. 2/O... Fig. 4/O) on the motor flange.
- A) Start the motor briefly (max. two seconds) to check the direction of rotation. When looking at the motor blower, it must rotate counter-clockwise.



## **NOTICE**

#### Incorrect direction of rotation

Running in reverse for a long time may damage the machine.

Use a phase sequence indicator to check the direction of rotation (**clockwise**).

# 6.2 Decommissioning/ storing

#### Stop the machine

- a) Switch the machine off.
- b) If available close the cut off device in the suction and pressure pipe.
- c) Disconnect the machine from the electricity source.
- d) Depressurise the machine:Open the pipes slowly.⇒ The pressure reduces slowly.
- e) Remove the pipes and hoses.
- F) Seal the connections for suction and pressure nozzles using adhesive foil.
- See also Section 3.2.1, Page 11

#### 6.3 Re-commissioning

- a) Check the condition of the machine (cleanliness, cabling etc.).
- For installation see Section 5, Page 17
- For commissioning see Section 6.1, Page 20



# 7 Maintenance and repair





## **DANGER**

# Danger of death from touching live parts!

Before maintenance work disconnect the machine by pressing the main switch or unplugging it and ensure that it cannot be turned on again.





## **WARNING**

#### Hot surfaces

During maintenance work there is the danger of getting burnt on hot components (Fig. 2/Q... 4/Q) of the machine.

Wait for the machine to cool down.

## 7.1 Ensuring operational safety

Regular maintenance work must be carried out in order to ensure operational safety.

Maintenance intervals also depend on the operational demands on the machine.

With any work observe the safety instructions described in Section 2.8 "Safety notes for installation, commissioning and maintenance".

The whole plant should always be kept in a clean condition.

## 7.2 Maintenance work

Interval	Maintenance activities	Section
Monthly	Check the pipes and screws for leaks and to ensure they are seated properly and if necessary seal again or tighten up.	
Monthly	Check the terminal box and cable inlet holes for leaks and if necessary re-seal.	_
Monthly	Clean the control valve and ventilation slots on the machine and the motor cooling ribs.	_
Monthly	Check the oil level	7.2.1
5,000 h	Change the oil	
Monthly/ every 6 months	C-VLR 60: Clean or replace filter cartridge	7.2.2
Depending on how dirty the discharged medium is	C-VLR 100 - 251: Clean micro filter	
At least once a year	Check for clutch wear	7.2.3



# 7.2.1 Changing the oil




Fig. 6 Change the oil

- H Oil filling point with vent screw
- I Oil sight glass
- K Oil discharge point
- M Oil recommendation plate

# Change the oil:

## **NOTICE**

Always change the oil when the machine is at operating temperature and in an atmospherically ventilated area.

If it is not completely emptied, the refilling quantity will be reduced.

The waste oil must be disposed of in compliance with the local environmental protection regulations. If you change the type of oil, empty the oil tank completely.

A minimum oil quantity can get out of the oil filling point by pressure compensation.

If larger quantities of oil escape, wash the internal filter of the vent screw.

The oil levels in the sight glasses (Fig. 6/I) must be checked every month.

To refill the oil level, it is required to switch off the machine and to bleed it to atmospheric pressure. Oil change has to be done after 5,000 operating hours.

The oil viscosity must comply with ISO-VG 150 or 220 as per ISO 3448.

Designation as per DIN 51502: CLP HC 150. We recommend the following brands of oil: GEAR-LUBE 150 or GEAR-LUBE 220 (Variant 31+32) or equivalent oil of other manufacturers (see also oil recommendation plate (Fig. 6/M)).



## 7.2.2 Air filtering




Fig. 7 Vacuum compressor intake filter

**f**<sub>2</sub> Filter cartridge

m<sub>2</sub> Bracket




Fig. 8 Purging filter cartridge

1 Filter cartridge

2 Compressed air

# NOTICE

## Insufficient maintenance on the air filter

The power of the machine lessens and damage may occur to the machine.

# Vacuum compressor intake filter (C-VLR 60)

The filter cartridges (Fig. 7/f<sub>2</sub>) for the intake filter (Fig. 2/S) must be cleaned monthly or more often depending on the level of contamination by purging from the inside outwards. In spite of cleaning the filter its separation efficiency will continue to deteriorate. Therefore the filter should be replaced every six months.

Filter cartridge can be removed (Fig. 7/f<sub>2</sub>) after releasing the brackets (Fig. 7/m<sub>2</sub>).

## **NOTICE**

Do not damage the filter cartridges when cleaning them.

# Micro filter (C-VLR 100-251)

The micro filter inbuilt in the intake silencer (Fig.  $3/S_1$ , Fig.  $4/S_1$ ) must be cleaned or replaced more or less often depending on how dirty the medium in it is by washing or blowing through.



#### **WARNING**

# Danger of injury when dealing with compressed air

When blowing through with compressed air, solid particles may be carried along or powder dust swirling around may cause injury to the eyes.

Therefore, when cleaning with compressed air always wear goggles and a dust mask.



# 7.2.3 Clutch




Fig. 9 Coupling C-VLR 60

k Clutch sprocket

m Motor

n₁ Housing

q Clutch half on the motor side

s₄ Screws




Fig. 10 Coupling C-VLR 100 - 251

k Clutch sprocket

m Motor

**n**<sub>2</sub> Fan housing

q Clutch half on the motor side

s<sub>5</sub> Screws

**v** Fan

The clutch sprocket (Fig. 9/k, 10/k)) is subject to wear and must be checked regularly (at least once a year).



#### **CAUTION**

#### **Defective clutch sprocket**

Defective sprockets may lead to the rotor shaft breaking.

To check the clutch switch the motor (Fig. 9/m, Fig. 10/m) off and ensure that it cannot be switched on again.

#### **C-VLR 60**

Undo the screws (Fig.  $9/s_4$ ) on the housing flange (Fig.  $9/n_1$ ). Remove the motor axially with the half of the clutch on the motor side (Fig. 9/q) and suspend with the lifting device. If the sprocket (Fig. 9/k) is damaged or worn, then replace it.

#### C-VLR 100-251

Undo the screws (Fig.  $10/s_5$ ) on the motor flange. Remove motor and the clutch half (Fig. 10/q) from the valve housing (Fig.  $10/n_2$ ) axially and suspend with a lifting device. If the sprocket (Fig. 10/k) is damaged or worn, then replace it. The fan (Fig. 10/v) should also be checked for damage from time to time and replaced if necessary.

## **NOTICE**

Frequent starting up and high ambient temperature

The service life of the sprocket (Fig. 9/k, Fig. 10/k) is reduced as a result of this.

Re-assemble in reverse order.



# 7.3 Repair/ Service




Fig. 11 Declaration of harmlessness 7.7025.003.17

a) For on-site repair work the motor must be disconnected from the mains by a qualified electrician so that it cannot be started up again accidentally. For repairs use the manufacturer, its branch offices or authorised dealers. Please contact the manufacturer for the address of the authorized service centre (see manufacturer's address).

# **NOTICE**

For each machine that is sent to an Elmo Rietschle Service centre for inspection, maintenance or repair, a fully completed, signed declaration of harmlessness must be enclosed.

The declaration of harmlessness is part of the supplier's documentation.

b) After a repair or re-commissioning, the actions listed under "Installation" and "Commissioning" must be carried out as for initial commissioning.



# 7.4 Spare parts




Fig. 12 Spare parts list (example)



Fig. 13 Website http://www.service-er.de

Order spare parts in accordance with the:

Spare parts list:

**E 880/1** → C-VLR 100

**E 880/3** → C-VLR 60

**E 880/4** → C-VLR 150

**E 880/5** → C-VLR 251 (01)

• Download the PDF file:

# http://www.gd-elmorietschle.com

- → Downloads
- → Product Documents
- → C-Series → Spare Parts
- Parts subject to wear and gaskets are indicated separately on the list.

## Website:

#### http://www.service-er.de

• Select the type, size and design.

# **NOTICE**

Only use original spare parts or parts approved by the manufacturer. The use of other parts may lead to malfunctions and invalidate liability or the guarantee for any consequences arising.



# 8 Malfunctions: Causes and elimination

Error	Cause	Troubleshooting	Important
Machine is switched off by the motor protection switch	Mains voltage/ Frequency does not correspond with the motor data	Check by qualified electrician	Section 5.6
	Connection to motor terminal board is not correct		
	Motor protection switch is not set correctly		
	Motor protection switch is trig- gered too quickly	Use a motor protection switch with an overload-dependent delayed switch off that takes into consideration the short term excess current at start up (version with short circuit and overload trigger as per VDE 0660 Part 2 or IEC 947-4)	
	The control valve is dirty so that the permissible vacuum value is exceeded	Clean or replace the control valve	Section 7.2 Section 7.4
Suction capacity is insufficient	The intake filter is dirty	Clean or replace the intake filter	Section 7.2.2 Section 7.4
	The suction pipe is too long or too narrow	Check the hose or the pipe	Section 5.3
	Machine or system leaking	Check the pipework and screw connections for leaks check for tight fitting	Section 7.2
Final pressure (max. vacuum) is not reached	Machine or system leaking	Check the pipework and screw connections for leaks check for tight fitting	Section 7.2
Machine gets too hot	Ambient or intake temperature is too high	Ensure it is being used properly	Section 2.3
	Cooling air supply is obstructed	Check ambient conditions	Section 5.1
		Clean ventilation slots	Section 7.2
	The control valve is dirty so that the permissible vacuum value is exceeded	Clean or replace the control valve	Section 7.2 Section 7.4
The machine makes a funny noise	Deposits on the rotary piston	Clean the working space and the rotary piston	Elmo Ri- etschle Ser- vice
	The control valve is vibrating	Replace the valve	Section 7.4



# 9 Technical Data

C-VLR			60	100	150	251
Sound pressure level (max.)	dB(A)	50 Hz	82	81	85	81
EN ISO 3744 Tolerance±3 dB(A)		60 Hz	84	84	88	84
Sound power level	dB(A)	50 Hz	93	93	97	92
		60 Hz	96	96	101	97
Weight*	kg		51	119	133	151
Length*	mm		662	730	846	1060
Width	mm		434	540	537	635
Height	mm		295	360	375	375
Vacuum connection			G1	G 1 <sup>1</sup> / <sub>2</sub>	G 1 <sup>1</sup> / <sub>2</sub>	G2
Exhaust air-outlet			G1	G11/2	G11/2	G2
Oil fill quantity	I		0.4	0.55	0.6	0.6

<sup>\*</sup> The length and the weight may differ from the information listed here depending on the motor manufacturer.



# **Technical Data**




Fig. 14 Data sheet (example)

Please will find more technical data on the data sheets **D 880** and **D 880-31** 

• Download the PDF file:

**D 880** → C-VLR 60, 100, 150, 251 **D 880-31** → C-VLR 60 (31), 100 (31), 150 (31)

• Download the PDF file:

## http://www.gd-elmorietschle.com

- → Downloads
- → Product Documents
- → C-Series → Data Sheets

# NOTICE

Subject to technical changes!





# www.gd-elmorietschle.com

er.de@gardnerdenver.com

# Gardner Denver Schopfheim GmbH

Roggenbachstraße 58 79650 Schopfheim · Germany Phone +49 7622 392-0 Fax +49 7622 392-300



Elmo Rietschle is a brand of Gardner Denver's Industrial Products Division and part of Blower Operations.



# EC - declaration of conformity 2006/42/EC

Hereby the manufacturer Gardner Denver Schopfheim GmbH

confirms:

Postfach 1260

D-79642 Schopfheim

that the machine:

vacuum pump

of the:

Series: C-VLR

Type:

C-VLR 60, C-VLR 100, C-VLR 120, C-VLR 150, C-VLR 250, C-VLR 251,

C-VLR 300, C-VLR 250, C-VLR 251, C-VLR 300, C-VLR 400, C-VLR 500, C-VLR 301, C-VLR 401, C-VLR 501,

C-VLR 1000

is conform to the regulations of the guideline indicated above.

The following harmonized and national standards and specifications are applied:

EN 1012-2:1996+A1:2009 Compressors and vacuum pumps — Safety requirements — Part 2:

Vacuum pumps

These declarations of conformity are invalid when the machine has been modified without prior approval by us and the approval has been documented in writing.

Name and address of the EC person in

charge for documentation

Gardner Denver Schopfheim GmbH

Postfach 1260

D-79642 Schopfheim

Gardner Denver Schopfheim GmbH

Schopfheim, 1.3.2015

Dr. Friedrich Justen, Director Engineering

C\_0080\_EN



# Safety declaration form for vacuum pumps and components

7.7025.003.17

Page 1 of 1

Gardner	<b>Denver</b>	Schopfheim	<b>GmbH</b>
---------	---------------	------------	-------------

Roggenbachstr. 58, 79650 Schopfheim

Phone: +49/(0)7622/392-0 Fax: +49/(0)7622/392-300

Repairs and/or maintenance of vacuum pumps and components will only be carried out if a declaration has been filled in <u>correctly and completely</u>.

This declaration must only be				d staff.				
1. Type of vacuum pumps	2. Reason for the submission							
Type description:  Machine number  Order number:  Delivery date:								
3. Condition of vacuum pu	umps/ com	ponents	4. Contamir	nation of the	vacuur	n pu	mps/	
Was this being operated? YES NO Which lubrication was used?  Was the pump/ component emptied?  (Product/Consumables) YES NO Has the pump/ component been cleaned and decontaminated and is it free of oil and grease and toxic substances that are harmful to health? YES				nts when in	use YES □ NO □ YES □ NO □			
			Explosive*) Radioactive*) other	YES YES	_ _ _	NO NO NO	_ 	
Cleaning agent: Cleaning method:								
*) Microbiological, explosive or with proof that they have been Type of toxic substance or procomponents came into contact	en cleaned process-related,	roperly.				•		ted
Trade name, manufacturer's product name	Chemical name	Hazard class	Action to be to substances a		First aid in the event of accidents			nt of
1 2								
3								
4								
Personal protection measures	:	-						
Hazardous decomposition products when subjected to thermal load  YES  NO  Which?								
5. Legally binding declara	tion							
We swear that the information position to judge this. We are a inaccurate information. We un from incomplete or incorrect in to third parties including in particular to the swear that the information in particular that is the swear that the information is the swear that the information position to judge this. We are a swear that the information position to judge this. We are a swear that the information position to judge this.	aware that we dertake to re formation. W	e are liable to lease the cont e are aware the	the contractor ractor from any nat, regardless	for damage ca y damage clair of this declara	used by ns from ation, we	incoi third are (	mplete parties directly	and arising liable
Company:								
Street: Post code/ Town:								
Phone:			Fax: Position:					
Name (in capitals)			_ Position:					
Date:			_Company stamp:					
Legally binding signature:		Tom:		Ieu	\======	· · · · · ·		
TOS no. / Index: 7 7025 003 17 / 03		I Office responsit	ne. (3S	It lie management	· \770250	เกร17 י	XIS	